Tutorial para o uso do Capstone com o sensor Hall

Abra o software PASCO Capstone



Clique em Hardware Setup Será mostrada a janela abaixo



Clique na porta que o sensor está inserido (normalmente A) e selecione "Magnetic Field Sensor"



Clique em "properties" e a janela abaixo será mostrada. Ajuste o ganho (gain) de acordo com selecionado no sensor. Clique em OK.



Na janela principal, escolha "Table & Graph"



Clique em <Select Measurement> -> Create New -> User-Entered Data



Clique em <Select Measurement> e escolha o ganho apropriado

	Page #	× Dispiby Journal × 🗎 🔄 🔀 ±1 🗵			-	-	_	_	-	_	
Tools X		1 4 4 4		🖗 🗏 🙎 📌 🌺 👁	2						Displays X
		[Table title here]			ſ						
			🔺 Set	<no data="" selected=""></no>							Graph
Setup			User Data 1 (units)	<pre><select measurement="">)</select></pre>							
 Data		1									scope
Summary		2		Rename	5						FFT FFT
		3									14
Calibration		4		Magnetic Field Strength (1X) (T	2						Histogram
		5		Magnetic Field Strength (10X) (1.23
Calculator		6		Use Entered Data							Digits
<u>"L</u>		7		User Date 3 (unite)							
Signal Generator		8		Equations/Constants							Meter
		0 9		Constants	•						Tabla
		10		Time							
		11		Index							Text Box
		12		Index							/
		13			-5						Text Entry Box
		14			-						
		15			-						Image
		16									Movie
		17			-						
		18			-10						Placeholder
		19				0	2	4	6	8	10
		20						<select measure<="" td=""><td>ment></td><td></td><td></td></select>	ment>		
		21	0		[Graph title h	ere]					
		0	0	(
											Controls 🗙
		Record Continuous	+ 00:00,00 Mode Ready	Magnetic Field Sensor - 10,00	Hz Condition	g Delete Last Ru					•
	e		🥥 🕑 🖪		-					PT 🔒	I7:24 12/04/2016

Selecione a unidade desejada

Untitled.cap* — F	PASCO Capst	one		1							l	- 0 X
<u>r</u> ile Ealt Workd		ay journal Help	• 🔛									
T 🚳 🔛 Page	+1 🛛				_							
Tools X	Table	itite here]	7 🖧 🗒 🖹 🖈 🏶 🔹	2]	Displays X
		🔺 Set	<no data="" selected=""></no>									
Hardware Setup		User Data 1 (units)	Magnetic Field Strength (10X) ((T))									Graph
Data	1		gauss mT									scope
Summary	2		J T	5	_							FFT
Calibratian	3											14
	4											Histogram
Calculator	5			lent								1.23
0	6			Irem								Digits
Signal	7			0 sst								eter Meter
Generator	8			ΨŬ								
	0 9											Table
	10			v S								
	11											Text Box
	13			-5								Text Entry Box
	14											*
	15											Image
	16											2
	17											Movie
	18			-10								Placeholder
	19					0	2	4	6	8	10	
	20							<pre>Select Measur</pre>	rement>)			
	21			[Graph titl	e here]							
	0	0										
	Record	Continuous Mode	Magnetic Field Sensor - 10,00 H	Hz	o rding itions	Delete Last Run					Controls	×
🚯 🥝		0 🧳 🙋 🙆	¥ 🚿 🍊 👘						· · · ·	PT 🔺	P 🖬 🖬 🕪	17:24 12/04/2016

No gráfico, escolha os eixos (Magnetic field no y e a distância em x)

	B
0.8	В
0.8	
0,4	
8	
윤 · · · · · · · · · · · · · · · · · · ·	
Add imilar Measurement	
Quicl Calc 🕨	
🖗 Magretic Field Sensor	
Mag letic Field Strength (1X) (T)	
Machetic Field Strength (10X) (1)	
Usentered Data	
User Data 1 (units)	8 10
Equations/Constants Time (s)	5 10
Constants	
Time (s)	(
Index	
	COOT GOO GOO <tr< td=""></tr<>

Selecione a opção Keep Mode. Você pode escolher a taxa de amostragem (sampling) logo ao lado

Untitled.cap	* — PASCO Capstor Norkbook Display	ie Journal Help	- 88				-			-					
🚞 🌼 🔡 F	Page #1 🗵														
Tools X	[Table fit	te here]												Displays X	¢
		set	<no data="" selected=""></no>										B		
Hardware Setup	-	User Data 1 (units)	Magnetic Field Strength (10X) (T)		0,8									Graph	
A Data	1													Scope	
Summary	2													EFT.	
٠	3			Ē	0.4 -									14	
Calibration	4			N N										Histogram	
Calculator	5) (IC										1.23	
M	6			đ										Digits	
Signal	7			Stre	0,0 -									Meter	
Generator	8			ield											
	9			ťά										Table	
	10			gne											
	12			Σ	-0,4 -									Text Box	
	13													Text Entry Bo	×
	14														
	15													Image eff:	
	16				-0,8	_								Movie	
	17														
	18							2		4	6	0		Placeholder	J
	19						0	2	Use	4 r Data 1 (ur	its)	ŏ		10	
	20			[Crow	ob titla	baral									
	21			LOID	pri uuc	fiere j									
			_											Controls Y	
	Fecord	🔅 🗸 00:00,00	O Magnetic Field Sensor → 10,00 H	iz 🔺	Ri cord Fonditi	ing De	elete Last Run								
@ (9	Keep Mode Fast Monitor Mode								~			PT 🔺 🏴 🖁	17:28 () 12/04/2016	

Para iniciar a medida, clique em "preview". O botão vai se tornar "ston"

Juntitled.c	ap* — PA	ASCO Capsto	one		100									
	vvorkbo	ok Displa	ay journal Help 💽 🔽 介 🔿 👘 -											
	🔲 Pac	ge #1 🗵				_								
Tools X				k 🗄 🖹 🗶 🌺 👁										Displays 🗙
•		[Table 1	title here]	C				İ						*
			<no data="" selected=""></no>	🔶 Run #1									В	Graph
Setup			User Data 1 (units)	Magnetic Field Strength (10X) (T)		0,8 -							Run #1 🔹	
Data		1		-8E-4										scope
(A)		2												FFT
Calibration		3			E	0,4 -								ÌM.
		5			(X)									Histogram
Calculator		6			ے لیے									Digits
L		7			renç	0.0								2
Signal Generator		8			ad St	0,0 -								Meter
		09		(E G									Table
		10			neti									
		11			Mag	-0,4 -								Text Box
		13												Text Entry Box
		14												<u>*</u>
		15												lmage
		16				-0,8 -								Movie
		17												
		18						0	2	4	6	8	10	Placeholder
		20						-	-	User Data 1 (u	units)	5	10	
		21			[Gra	ph title	here]							
		U	•O	•										
													Control	ls x
	4	Stop	Keep Sample Keep Mode Record	2,91 Magnetic Field Sensor -	10,00 H	z 🛆	Recording Conditions	Delete Last					•	
	Ø	A	0 4 6	1 1 1									PT 🔺 🖿 🖬 口 () 17:31) 12/04/2016

Para manter a medida clique em "Keep Sample" e digite a distância do trilho na tabela

= 1= r ==+ +⊖ +⊖ +⊖ 0.00 0.0+ ······ 🝊 ·	- 😰 🍫 🗏 😫 📌 🏶 📃					
[Table title here]	0					
🔀 Set	🔶 Run #1					В
User Data 1 (units)	Magnetic Field Strength (10X) (T)	0,8 -			R	un #1 🔸
1 0	-8E-4					
2						
3		F 0,4				
4						
5		(10				
6		te la				
7		8,0,0				
δ 0		<u><u><u></u></u></u>				
10						
10		0 0				
12		Σ -0,4				
13						
14						
15						
16		-0,8				
17						
18						
19		0	2 4 User	Data 1 (units)	8	10
20		(Create Villa Incore)	0301			
21	d	[Graph title here]				

Antes de exportar, em data sumary escolha no botão olho apenas os dados que deseja exportar

Untitled.ca <u>File</u> Edit	ap*— PASCO Capstone Workbook Display Journal Help												
			_	_		_							
Tools X Hardware Setup Data Summary Calibration Calculator Calculator Signal Generator	Page #1 Data Summary Sensor Data Summary Magnetic Field Sensor Magnetic Field Strength (100X) (T) Run #1 Clock	Run #1 Field Strength (10X) (T) -8E-4 -8E-4 -8E-4 -8E-4 -9 Magnetic Field Strength (1X) Magnetic Field Strength (10X) Magnetic Field Strength (100X) Magnetic Field Strength	0,8 - 0,4 - 0,00,4 -								Run #	B #1 •	Displays X Graph Scope FFT Histogram 123 Digits Meter Table Table
	Image: Second system Image: Second system 02:26,30 Image: Second system Second system Second system Image: Second system Second system Second system <th>[Grag Magnetic Field Sensor v 10.00 H</th> <th>-0,8 -</th> <th>O O Recording Conditions</th> <th>20 Delete Last</th> <th>40</th> <th>60 Use</th> <th>80 r Data 1 (units</th> <th>100</th> <th>120</th> <th>140</th> <th>160 Centrols</th> <th>Text Entry Box</th>	[Grag Magnetic Field Sensor v 10.00 H	-0,8 -	O O Recording Conditions	20 Delete Last	40	60 Use	80 r Data 1 (units	100	120	140	160 Centrols	Text Entry Box
1	🙆 🚞 🔉 🔄 🔮 🥵	1						~			PT 🔺	• # 🖬 🛛	17:36 12/04/2016

No botão engrenagem para cada conjunto de dados é possivel configurar a unidade e número de casas decimais a serem exportadas.



Finalmente exporte os dados para um arquivo texto.

Untitled.cap* — PASCO Capstone		
<u>File</u> Edit Workbook Display Journal He	Help	
New Experiment Ctrl+N		
Open Experiment Ctrl+O		
😹 Save Experiment Ctrl+S		Diselaus M
Save Experiment As		Displays X
Df		
	P Run #1	3 Cranh
Import Data	Field Strength (10X) 0.8 Run #1	•
Export Data ary		Scope
Recent Experiments	-8E-4	
Print Page Setup	-8E-4	EFT EFT
Print Praview		ta
Print Freview		Histogram
		102
0 E <u>x</u> it		Digits
<u></u>		
Signal		Meter
Generator		
		Table
		Text Box
	≥ -0,4	/
		Text Entry Box
		Image
		**
		Movie
		Placeholder
		50
	[Graph title here]	
		Controls X
	✓ 02:26,30 Magnetic Field Sensor → 10,00 Hz ▲	0
Preview Keep Sample	Keep Mode Ready Conditions Delete Last Run	
		17:36
		12/04/2016