

Tabela 5				
Pontos	V (V)	FE Usado (V)	I (mA)	FE Usado (mA)
1	-0,274	4	-2,80	40
2	-0,506	4	-5,14	40
3	-0,996	4	-10,19	40
4	-2,010	4	-20,55	40
5	-4,000	4	-40,8	200
6	-6,33	40	-64,6	200
7	-10,00	40	-102,1	200
8	-14,65	40	-150,0	200
9	0,107	4	1,09	40
10	0,505	4	5,16	40
11	1,000	4	10,22	40
12	2,000	4	20,44	40
13	5,00	40	51,0	200
14	10,00	40	102,1	200
15	12,00	40	122,4	200
16	14,70	40	150,2	200

Tabela 6				
Pontos	V (V)	FE Usado (V)	I (mA)	FE Usado (mA)
1	0,500	4	4,93	40
2	1,000	4	6,77	40
3	1,500	4	7,90	40
4	2,999	4	10,85	40
5	5,00	40	14,44	40
6	10,00	40	21,62	40
7	15,00	40	27,66	40
8	20,00	40	32,89	40
9	26,42	40	38,98	40
10	-0,499	4	-4,82	40
11	-0,994	4	-6,69	40
12	-1,519	4	-7,91	40
13	-2,993	4	-10,94	40
14	-4,98	40	-14,45	40
15	-10,01	40	-21,73	40
16	-28,52	40	-40,70	200