CodeWarrior Build Tools Options for Optimal Performance on HCS08 Cores

1 Introduction

This document describes two sets of options and pragmas that can be used with the CodeWarrior tools to produce optimal code for the HCS08 cores. One set optimizes the size of the code; another set optimizes the execution speed. You can use the build tools options and pragmas described in this document for optimal performance, but the build tools settings must be set according to the application being developed.

For more information on the HCS08 Compiler, refer to CodeWarrior Development Studio for Microcontrollers V10.x HC(S)08 Build Tools Reference Manual by Freescale.

2 Optimization for Size

Several strategies can be used, simultaneously if the application allows, to optimize the size of the generated code:

- use specific compiler options
- choose a less expensive memory model

Contents

1	Introduction	1
2	Optimization for Size	1
3	Optimization for Speed	:



Optimization for Size

place code and/or data in segments which require shorter addressing.

The following sections provide details on each of these approaches.

For additional hints on code size optimization, refer to topic Generating Compact Code in CodeWarrior Development Studio for Microcontrollers V10.x HC(S)08 Build Tools Reference Manual by Freescale.

2.1 Compiler Options

For compact code, pass the following options to the compiler:

```
-Os -Ous -Of
```

A specific set of options may reduce the code size for some functions, but increase it for other functions in the same compilation unit. In order for the compiler to dynamically configure options for each function, invoke it with option -OdocF. This option takes a list of option sets as input, and instructs the compiler to run with each option set and keep the one that produces the best code size for each function. For example: -OdocF = "-Or | -Cni -Cu | -Oc".

NOTE The compilation time multiplies by a factor equal to the number of option sets passed to the compiler.

2.2 Memory Models

The TINY memory model is the least expensive one - with the BANKED memory model being the most expensive. Use the TINY memory model if the application allows, that is, all data, including stack, fits into the zero page area (between 0 and 0xFF). Use the SMALL memory model if the application code and data fits into the 64KB address space.

To select TINY as the memory model, pass option -Mt to the compiler. To select SMALL as the memory model, invoke the compiler with option -Ms.

For more information on memory models, refer to topic Memory Models in CodeWarrior Development Studio for Microcontrollers V10.x HC(S)08 Build Tools Reference Manual by Freescale.

2.3 Compiler Pragmas for Data and Code Allocation

If the selected memory model is either SMALL or BANKED, use __SHORT_SEG data segments in order to allocate a subset of the application data on the zero page (0 to 0xFF). Objects allocated on this page are accessed using 8-bit addressing. To specify that a data segment is a __SHORT_SEG segment, use modifier __SHORT_SEG with either a CONST_SEG or a DATA_SEG pragma.

For example:

```
#pragma DATA_SEG __SHORT_SEG MY_ZEROPAGE
unsigned int var1; /* 8b access */
#pragma DATA SEG DEFAULT
```

CodeWarrior Build Tools Options for Optimal Performance on HCS08 Cores Application Note

2 Freescale Semiconductor

```
unsigned int var2; /* 16b access */
```

If the selected memory model is BANKED, use __NEAR_SEG code segments in order to mark a subset of the application functions as __near. Such functions are accessed using 16-bit addressing (instead of the default 24-bit addressing). To specify that a code segment is a __NEAR_SEG segment, use modifier __NEAR_SEG with a CODE_SEG pragma.

For example:

```
#pragma CODE_SEG __NEAR_SEG NON_BANKED
void foo() {} /* JSR/RTS */
#pragma CODE_SEG DEFAULT
void bar() {} /* CALL/RTC */
```

For more information on data/code placement pragmas, refer to topic Pragma Details in CodeWarrior Development Studio for Microcontrollers V10.x HC(S)08 Build Tools Reference Manual by Freescale.

3 Optimization for Speed

In order to reduce the overall cycle count of the code, pass the following options to the compiler:

```
-Ot -Cu -Ous -Onf -Oi -OiLib
```

To further improve execution speed, configure the compiler to use shorter addressing:

-select the least expensive memory model that the application allows (refer to section 2.2 for more details)

-allocate some of the application data objects and functions in segments that require shorter than default addressing: 8-bit, instead of 16-bit, for data, with either the SMALL or the BANKED memory model; 16-bit, instead of 24-bit, for code, with the BANKED memory model (refer to section 2.3 for more details).

CodeWarrior Build Tools Options for Optimal Performance on HCS08 Cores Application Note

Freescale Semiconductor 3

How to Reach Us:

Home Page: www.freescale.com

E-mail: support@freescale.com

US A/Europe or Locations Not Listed: Freescale Semiconductor Technical Information Center, CH370 1300 N. Alma School Road Chandler, Arizona 85224 +1-800-521-6274 or +1-480-768-2130 support@freescale.com

Europe, Middle East, and Africa: Freescale Halbleiter Deutschland GmbH Technical Information Center Schatzbogen 7 81829 Muenchen, Germany +44 1296 380 456 (English) +46 8 52200080 (English) +49 89 92103 559 (German) +33 1 69 35 48 48 (French) support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd. Headquarters ARCO Tower 15F 1-8-1, Shimo-Meguro, Meguro-ku, Tokyo 153-0064, Japan 0120 191014 or +81 3 5437 9125 support.japan@freescale.com

As ia/Pacific:

Freescale Semiconductor Hong Kong Ltd. Technical Information Center 2 Dai King Street Tai Po Industrial Estate Tai Po, N.T., Hong Kong +800 2666 8080 support.asia@freescale.com Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

Freescale, the Freescale logo, CodeWarrior and ColdFire are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. ColdFire+, Kinetis, Processor Expert, and Qorivva are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. ARM is the registered trademark of ARM Limited. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© 2011 Freescale Semiconductor, Inc. All rights reserved.

Document Number: AN4414

23 November 2011

