

Engine Layout and Load Diagrams

Introduction

The effective power 'P' of a diesel engine is proportional to the mean effective pressure p_e and engine speed 'n', i.e. when using 'c' as a constant:

$$P = c \times p_e \times n$$

so, for constant mep, the power is proportional to the speed:

$$P = c \times n^1 \text{ (for constant mep)}$$

When running with a Fixed Pitch Propeller (FPP), the power may be expressed according to the propeller law as:

$$P = c \times n^3 \text{ (propeller law)}$$

Thus, for the above examples, the power P may be expressed as a power function of the speed 'n' to the power of 'i', i.e.:

$$P = c \times n^i$$

Fig. 2.01.01 shows the relationship for the linear functions, $y = ax + b$, using linear scales.

The power functions $P = c \times n^i$ will be linear functions when using logarithmic scales:





Fig. 2.01.01: Straight lines in linear scales



178 05 40-3.1

Fig. 2.01.02: Power function curves in logarithmic scales

Thus, propeller curves will be parallel to lines having the inclination $i = 3$, and lines with constant mep will be parallel to lines with the inclination $i = 1$.

Therefore, in the Layout Diagrams and Load Diagrams for diesel engines, logarithmic scales are used, giving simple diagrams with straight lines.

Propulsion and Engine Running Points

Propeller curve

The relation between power and propeller speed for a fixed pitch propeller is as mentioned above described by means of the propeller law, i.e. the third power curve:

$$P = c \times n^3, \text{ in which:}$$

P = engine power for propulsion


n = propeller speed

c = constant

Propeller design point

Normally, estimates of the necessary propeller power and speed are based on theoretical calculations for loaded ship, and often experimental tank tests, both assuming optimum operating conditions, i.e. a clean hull and good weather. The combination of speed and power obtained may be called the ship's propeller design point (PD),

placed on the light running propeller curve 6. See below figure. On the other hand, some shipyards, and/or propeller manufacturers sometimes use a propeller design point (PD) that incorporates all or part of the so-called **sea margin described below.**



- Line 2 Propulsion curve, fouled hull and heavy weather (heavy running), recommended for engine layout
- Line 6 Propulsion curve, clean hull and calm weather (light running), for propeller layout
- MP Specified MCR for propulsion
- SP **Continuous service rating for propulsion**
- PD Propeller design point
- HR Heavy running
- LR Light running

178 05 41-5.3

Fig. 2.01.03: Ship propulsion running points and engine layout

Fouled hull

When the ship has sailed for some time, the **hull and propeller become fouled and the hull's resistance will increase.** Consequently, the ship's speed will be reduced unless the engine delivers more power to the propeller, i.e. the **propeller will be further loaded and will be heavy running (HR).**

As modern vessels with a relatively high service speed are prepared with very smooth propeller and hull surfaces, the gradual fouling after sea trial will increase the hull's resistance and make the propeller heavier running.

Sea margin and heavy weather

If, at the same time the **weather is bad, with head winds, the ship's resistance may increase compared to operating in calm weather conditions.** When determining the necessary engine power, it is normal practice to add an **extra power margin,**

the so-called **sea margin,** which is traditionally about **15% of the propeller design (PD) power.**

Engine layout (heavy propeller)

When determining the necessary engine layout speed that considers the influence of a heavy running propeller for operating at high extra ship resistance, it is (compared to line 6) recommended to choose a heavier propeller line 2. The propeller curve for clean hull and calm weather line 6 may then be said to represent a 'light running' (LR) propeller.

Compared to the **heavy engine layout line 2,** we recommend using a **light running of 4.0-10.0% for design of the propeller.**

Engine margin

Besides the sea margin, a so-called '**engine margin**' of some 10% or 15% is frequently added. The corresponding point is called the '**specified MCR for propulsion**' (MP), and refers to the fact that the power for point SP is 10% or 15% lower than for point MP.

Point **MP is identical to the engine's specified MCR point (M)** unless a main **engine driven shaft generator is installed.** In such a case, the extra power demand of the shaft generator must also be considered.

Constant ship speed lines

The **constant ship speed lines α ,** are shown at the very top of the figure. They indicate the power required at various propeller speeds in order to keep the same ship speed. It is assumed that, for **each ship speed, the optimum propeller diameter is used, taking into consideration the total propulsion efficiency.** See definition of α in Section 2.02.

Note:

*Light/heavy running, fouling and sea margin are overlapping terms. Light/heavy running of the propeller refers to hull and propeller deterioration and heavy weather, whereas sea margin i.e. extra power to the propeller, refers to the influence of the wind and the sea. However, the **degree of light running must be decided upon experience from the actual trade and hull design of the vessel.***